
Linear · PD SERIES Red 625 nm

USER MANUAL







1. Product Description

LED luminaire suitable for installation in electrical panels, machinery, home, elevators, machine vision, etc.

Structure made of silver anodized aluminum with multiple options. Equipped with the latest generation LEDs, the internal electronics allow direct connection to a power source, thus extending the life of the luminaire. In vision luminaires, a protection system is included to avoid exceeding the recommended triggering time.

2. Safety Tips

LUMHER luminaires have been manufactured according to the technical specifications specified for each model, using high-quality components and following a delicate production process.

Each production detail has been carefully crafted, from the manufacture of the electronic circuit to the final packaging, maintaining all quality criteria.

- Users should consider the following safety tips regarding the product.
 - This manual should be kept close to the luminaire.
 - It is important that users read all instructions before connecting the luminaire.
 - Follow the instructions in this document
 - Install the product taking into account the safety risks specified in this document.
 - LUMHER is not responsible for improper use of this luminaire.

2.1. Correct Use of the Luminaire

The product classification is IP40 or IP65 depending on the selected model, so this information must be considered when using the luminaire.

2.2. Product Safety

If the luminaire is not used correctly, it may be harmful to individuals due to electrical risks.

- The connection should ONLY be made by qualified personnel.
- Disconnect the power before performing any manipulation of the luminaire.
- The luminaire must comply with all the requirements indicated on the product label.
- Maintenance and repair should be carried out only by qualified personnel.
- There may be a risk of explosion if the luminaire is used in explosive environments.
- Do not install the luminaire in explosive environments.

Installation and Safety

- Avoid hitting the luminaire, even with packaging. It is a fragile product. Strong impacts may damage the luminaire.
- Use only the fastenings provided by the manufacturer.
- Properly use the mounting fixings.

- The luminaire must be securely fastened with the appropriate screws depending on the installation surface.
- Periodically check that the luminaire is properly installed.

Glare Hazard

- Avoid looking directly at the luminaire, as it may cause temporary vision problems, irritation, and eye
 pain.
- Do not look directly at the light source.
- Adjust the luminaire so that the light source does not directly impact the operator's eyes.

Hazard from Non-Original Spare Parts

• Always use original spare parts from the manufacturer.

Damage Due to High Temperatures

Install the luminaire in environments where there is no high temperature. A temperature above the maximum operating range can drastically reduce the luminaire's lifespan. Avoid direct sunlight.

Damage Due to Repairs

Do not disassemble or repair the equipment if not done by qualified personnel. Improper repairs may cause damage to people and objects. In case of failure, do not repair; return to technical support. Any modification of the product not performed by the technical service will void the warranty.

2.2. Risk Levels

DANGER: Risk in case of non-compliance. It may cause immediate injury or even death. WARNING: Risk in case of non-compliance. It may cause injuries or even death. ATTENTION: Risk in case of non-compliance. It may cause immediate injuries. ADVICE: Risk in case of non-compliance. It may cause damage to objects.

3. Versions

The product code can be found on the luminaire label and packaging. Find the luminaire code on the packaging label and verify the item with the product label.

The barcode on the label shows the week and year of manufacture.

Do not remove the product label, as it will facilitate traceability in case of return due to failure or malfunction. If the luminaire does not have a label, it will lose its warranty.

4. Technical specifications

5. Connection

Power supply voltage	24 Vdc ±5%		
Trigger input	24 Vdc PNP / NPN		
Max. on time	Continuous = unlimited	Strobe = 10 ms	
Max. working cycle	Continuous = 1 Strobe = 1/		
Max. consumption Trigger input	1,5 mA		
Max. number of cascadable modules	This luminaire is not cascadable		
Wavelength	Red	625 nm	
Beam angle	Semidiffuse Ultradiffuse	60° 110°	
Electrical protections	Transient overvoltages Polarity reversal Current sabilizer	YES YES YES	
IP Rating	IP40 o IP65		
Protection type	Class III		
Operating temperature	-10 °C to +40 °C		
Storage temperature	0°C to +60 °C		
Max. relative humidity	80% (without condensation)		
Body material	Anodized aluminum		
Side cover material	Anodized aluminum		
Diffuser material	Polycarbonate		
Connection types	M12A, 2m cable, M12A connecto	r with cable	
Standards	RoHs, CE		

M12A input - Cable	Continuous	Master Continuous - Strobe	Slave Continuous - Strobe
Pin 1 – Brown	+24 Vdc	+24 Vdc	+24 Vdc
Pin 2 - White	Not connected	Trigger NPN	Not connected
Pin 3 - Blue	0 Vdc	0 Vdc	0 Vdc
Pin 4 - Black	Not connected	Trigger PNP	Signal IN - a

M12A Male



Fixings


POOG1, POOG2, POOG3, POOR1, POOR2, POOR3, POOR4, M6D16

PD · 625 nm

6. Measures


IP40

M12A axial version




M12A radial version

4




IP65


M12A axial version







7. Selection guide



Measures in mm





Model PD · Red 625 nm







Table of characteristics

	Length L1 ^տ	Length L2 ⁽¹⁾	Weight		us flux ⁽²⁾ m)		onsumed N)
	(mm)	(mm)	(g)	CONT.	STROBE	CONT.	STROBE
PD 01	120	138	97	97	388	1,9	7,6
PD 02	210	228	145	194	775	3,8	15,2
PD 03	300	318	193	291	1.163	5,7	22,8
PD 04	390	408	241	388	1.550	7,6	30,4
PD 05	480	498	289	485	1.938	9,5	38,0
PD 06	570	588	337	581	2.326	11,4	45,6
PD 07	660	678	385	678	2.713	13,3	53,2
PD 08	750	768	433	775	3.101	15,2	60,8
PD 09	840	858	481	872	3.488	17,1	68,4
PD 10	930	948	529	969	3.876	19,0	76,0
PD 11	1.020	1.038	577	1.066	4.264	20,9	83,6
PD 12	1.110	1.128	625	1.163	4.651	22,8	91,2
PD 13	1.200	1.218	673	1.260	-	24,7	-
PD 14	1.290	1.308	721	1.357	-	26,6	-
PD 15	1.380	1.398	769	1.454	-	28,5	-

(1) Versions with radial input and/or radial output will have as length L2, the rest will be L1.(2) The luminous flux (Im) is before diffuser.



8. Control



For Strobe mode operation, it is recommended that the power supply be twice as powerful as the Strobe mode lamp.

Maintain input voltage within the permissible range; incorrect voltage will damage the LED driver. **Permitted** voltage range: 24VDC±5%

Improper wiring can cause lamp breakage, material, and personal damage. Electrical connection must be carried out by qualified personnel. Strictly follow the indications shown in the connection section to ensure correct polarity.

9. Switching On and Off

The luminaire does not have automatic on/off functionality. This function is only available in vision models and versions with a presence sensor.

The luminaire turns on when receiving voltage and turns off when the voltage is removed.

The luminaire allows PWM dimming (except for machine vision models).

10. Troubleshooting

If the lamp does not turn on:

- Check that the lamp is correctly connected to the power source.
- Verify that the polarity of the connection pins is correct.

If the lamp is defective, contact: CONTAVAL S.L.U. (Lumher Technical Support) Telf. +34 963 843 700 Email: service@lumher.es

11. Replacing the Light Source

The light source is adhered to the profile using thermal adhesive glue. Thanks to the long lifespan of the LED, around 60,000 hours*, light source replacement will not be necessary if used as indicated in this manual. In case the light source needs to be replaced, contact the technical department. * Value for white LED

12. Product Maintenance and Cleaning

WARNING - Disconnect power before performing any maintenance tasks.

This product does not require special maintenance.

- Cleaning tasks should only be carried out after turning off the lamp and once the surfaces have cooled down.
- Then proceed to clean the lamp with a non-abrasive liquid and a soft cloth.
- Regularly check that the four mounting screws are properly tightened.

ADVICE - Liquid leaks can damage the lamp.

13. Repair and Warranty

During the product's lifespan, the warranty covers product analysis and repair exclusively by Lumher's technical department or an authorized distributor, including the following points:

- Custody of the material provided for repair
- Cost of components, including labor dedicated to the defective product

The warranty does not cover:

- Transportation, packaging, and shipping costs
- Deterioration or damage caused by:
 - Installation and/or operation different from what is described in this manual
 - Repairs or repair attempts by personnel not authorized by Lumher
 - Operation of the equipment in environmental conditions other than those specified in the luminaire's technical sheet
 - Damage caused by liquid leaks in the lamp
 - Damage during transportation due to not following proper indications or inadequate packaging (original packaging is recommended)

WARRANTY PERIOD: The warranty period is 36 months from the date of purchase. Once this period has expired, repair services will be provided at the cost of replacement parts and labor according to established rates.

14. Recycling

Disposal of Obsolete Electrical and Electronic Devices (Directive 2002/96/EC-WEEE):

The crossed-out trash bin symbol indicates that this product, as it contains electrical and electronic components, should not be mixed with untreated municipal waste. For more detailed information regarding the recycling of this product, check your country's waste disposal regulations. Do not dispose of this product as solid waste, even if it contains such components. Reuse or proper recycling of electrical or electronic equipment (EEE) is important to protect the environment and human health.

According to the European WEEE Directive 2002/96/EC, these types of products should be disposed of in electrical and electronic waste disposal areas. The equipment may be disposed of by the distributor when purchasing an equivalent. Public administrations and manufacturers of electrical and electronic equipment are involved in facilitating all processes for the reuse and recovery of discarded electrical and electronic equipment through collection campaigns using appropriate planning mechanisms.

Incorrect disposal of electrical or electronic waste may be punishable by law according to the sanctions established by each country.

15. Symbology

CE	CE Logo
	CLASS III DEVICE Device that works with extra-low voltages.
IP40 / IP65	IP Rating
LED TEC	LED Technology
	Directive 2002/96/EC of the European Parlia- ment and of the Council of 27 January 2003 on the disposal of Waste Electrical and Electronic Equipment (WEEE) (OJ L 37, 13.2.2003, p. 1).